

# Resetting the graphic calculator.

*This resource was written by Derek Smith with the support of CASIO New Zealand. It may be freely distributed but remains the intellectual property of the author and CASIO.*

Select **MEM** from the main menu by using the arrow keys to highlight **MEM** or by pressing the letter F.




## Resetting the Calculator

Resetting the calculator serves three main purposes:

1. It clears any previous operations that the current user may not be familiar with or want to use.
2. It returns the calculator to its initial default settings.
3. Viewing and deleting specific areas of the calculator's memory, usually in this case to 'free up' memory.

To select view the **MEMORY USAGE**, press **EXE**. Then use the down arrow followed by **F1** to reset the storage space memory to zero, followed by the **EXIT** key to return back to the previous screen, or the **MENU** key to return back to the menu screen.



To select **RESET**, use the down arrow followed by **EXE**. Press **F1** (YES) followed by the **MENU** key to return back to the menu screen.

