

Easy Guide to Setting Casio G Shock Giez Series – GS1001

Mode

To be able to set the time, the watch must first be in the timekeeping mode - this is indicated when the stopwatch second hand (long skinny hand on main dial) is pointing to the 12 O'clock position. It is also important that the hand on the bottom inside dial is turning – if not press the bottom right button.

If you are unsure of which mode the watch is in press the mode button (lower left) and allow the watch to cycle through to the next mode, repeat this step until the Stopwatch second hand rests on 'ALM' between the 10 & 11 O'clock position. Then press mode 1 more time and allow the watch to cycle, when the hands rest the watch is now in the timekeeping mode

Setting the Watch

Stage 1 – DST & Home City

1. Press and hold down the adjust button (top left), the hands will start moving, but keep holding down until the watch beeps. The watch is now in setting mode.
2. Press the top right button, this turns the daylight savings on or off – you will see the small hand on the bottom dial move, if it is 'off' the hand will need to complete a full turn to rest at the 'on' position.
3. Pressing the bottom right hand button will move the Stopwatch second hand by a few degrees; this indicates the world time zones which are shown as three letter codes on the inner dial ring. The home city for New Zealand is Wellington, which is abbreviated by WLG and is located at the 7 O'clock position. When the Stopwatch second hand is pointing to WLG, the home city is selected.
4. Press the mode button and the hands should automatically adjust to the correct time.

Stage 2 – Time Keeping Adjustment

1. If after completing stage one the correct time is not displayed you will be able to adjust the time manually using the bottom right button to scroll forward and the top left to scroll backward. Take care to ensure that the 24 Hour hand (small dial on left) is at the correct position.
2. Press the mode button (bottom left) to move into setting the date.

Stage 3 – Setting the Date

1. Use the top right button to move the stopwatch second hand and set the decade. E.g. the year 2008 will require the decades to be set to 00 which is the 12 o'clock position.
2. Pressing the bottom right moves the small hand on the bottom dial, this is for the year, so for 2008, the hand will point to the 8 on the small dial

3. Press mode (bottom left), this enables the month to be set. Pressing the bottom right button moves the second hand by 1hr at a time for each of the 12 months, for instance February is the 2hr, March is 3hr, April is 4hr and so on
4. Press mode (bottom left), this enables the day of the month to be selected. This is the small number panel in the bottom right hand corner of the dial – next to 'reset' on the outer bezel. Press either the top or bottom right to advance or reverse the day counter; you will see it move slowly.
5. Press the mode button (bottom left), the watch will beep twice and the stopwatch second hand will move back to the 12hr position.
6. Now press the top left, the stopwatch second hand will rotate once around the dial and the second hand in the bottom dial will begin turning. The watch is now set and the time and date is locked in.

Setting The Alarm

- Press mode button (bottom left) until you stopwatch seconds hand is facing ALM in top left.
- Press top left to toggle alarm on or off
- Hold down top left for 3 seconds until watch beeps. Now use top right to move alarm time backwards and bottom right to move alarm time forward (Hours = Triangle, Minutes = Straight hand)